❶ INSTALLATION



❷ INTERFACE CONNECTOR



Note: Connector interface is subject to model's specifications

Downloaded from www.Manualslib.com manuals search engine

English

Quick Start

❶ INSTALLATION

1. Power Cord
2. VGA Cable
3. Composite Video Cable
4. USB Cable
5. VGA to Component/HDTV Adapter
6. S-Video Cable
7. Audio Cable Jack/Jack
8. RS232 Cable
9. HDMI Cable
10. 3 RCA Component Cable
11. LAN Cable

Note: Connector interface is subject to model's specifications

❷ INTERFACE CONNECTOR

Connecting to a Computer

1. Ensure the projector and your computer are turned off.
2. Connect one end of the VGA cable to the "VGA IN" connector on the projector; connect the other end to the VGA connector on the computer and tighten the screws.
3. Connect one end of the power cord into the AC power socket on the projector; connect the other end to an electrical outlet.

Powering On the Projector

1. Remove the lens cap.
2. Turn on the projector first and then the computer.
3. Adjust the position, focus and zoom.
4. Run you presentation.

Powering Off the Projector

1. Press the power button twice.
2. Do not remove AC power cord from outlet until the projector fan shut down.

Français

DÉMARRAGE RAPIDE

❶ INSTALLATION

1. Cordon d'alimentation
2. Câble VGA
3. Câble Vidéo Composite
4. Câble USB
5. VGA vers Composant/Adaptateur HDTV
6. Câble S-Vidéo
7. Câble Audio Jack/Jack
8. Câble RS232
9. Câble HDMI
10. Câble de composant 3 RCA
11. Câble LAN

Remarque: L'interface du connecteur est sujette à spécifications du modèle

❷ CONNECTEURS D'INTERFACE

Connexion à un ordinateur

1. Assurez-vous que le projecteur et votre ordinateur sont hors tension.
2. Connectez une extrémité du câble VGA au connecteur "VGA IN" sur le projecteur. Connectez l'autre extrémité au connecteur VGA de l'ordinateur et serrez les vis.
3. Connectez une extrémité du cordon d'alimentation à la prise d'alimentation sur le projecteur. Connectez l'autre extrémité à une prise électrique.

Mise sous tension du projecteur

1. Retirez le protège-obectif.
2. Mettez le projecteur sous tension en premier, puis l'ordinateur.
3. Ajustez la position, effectuez la mise au point et zoomez.
4. Faites votre présentation.

Mise hors tension du projecteur

1. Appuyez le bouton d'alimentation deux fois.
2. Ne retirez pas le cordon d'alimentation de la prise avant que le ventilateur du projecteur ne s'arrête.

Downloaded from www.Manualslib.com manuals search engine